

HULK ICF SYSTEM 3 STEP PROCESS



HULK SYSTEMS

LET'S NOT OVER-COMPLICATE THINGS!
THE BASIC APPLICATION OF THE HULK SYSTEM
CAN BE BROKEN DOWN INTO 3 EASY STEPS!

STEP 0

ENSURE YOUR FOAM IS CLEAN

You never want to spray over loose foam, dirt, or other contaminants and risk adhesion.

STEP 1

SPRAY LIQUID WATERPROOFING (HULK WP)

Spray a thick layer of the membrane on your wall. You'll know you're at 35-40mils once you see a bit of sag (product drip).

STEP 2

INLAY THE TEXTILE (HULK SRT)

Lay the textile into the still-wet section of wall you just sprayed. Smooth out any wrinkles.

STEP 3

SPRAY LIQUID WATERPROOFING AGAIN (HULK WP)

Immediately spray over the textile again. You'll know you've applied enough material, when the texture of the fabric is no longer visible.



Call for a Free Consultation 208-315-9303



Email TBrown@BuildWithICF.com for details



3330 Black Butte Court, Nampa, Idaho 83687

