

# HULK ICF SYSTEM 3 STEP PROCESS



## HULK SYSTEMS

LET'S NOT OVER-COMPLICATE THINGS!  
THE BASIC APPLICATION OF THE HULK SYSTEM  
CAN BE BROKEN DOWN INTO 3 EASY STEPS!

### STEP 0

#### ENSURE YOUR FOAM IS CLEAN

You never want to spray over loose foam, dirt, or other contaminants and risk adhesion.

### STEP 1

#### SPRAY LIQUID WATERPROOFING (HULK WP)

Spray a thick layer of the membrane on your wall. You'll know you're at 35-40mils once you see a bit of sag (product drip).

### STEP 2

#### INLAY THE TEXTILE (HULK SRT)

Lay the textile into the still-wet section of wall you just sprayed. Smooth out any wrinkles.

### STEP 3

#### SPRAY LIQUID WATERPROOFING AGAIN (HULK WP)

Immediately spray over the textile again. You'll know you've applied enough material, when the texture of the fabric is no longer visible.



Call for a Free Consultation 1-833-485-5797



Email [info@hulkssystem.com](mailto:info@hulkssystem.com) for details



1512 Hastings Cres, Calgary, Alberta, T2G 4C9

